

Assembly Instructions

Building a unit(s) with a Backboard.

SHELFSTORE®

www.shelfstore.co.uk
www.shelvingsystem.co.uk



Tools Required

Hammer

Read all instructions before starting



Step 1

Tip:

Before starting, mark the **centre** of the uprights in several places with a pencil. This will ensure the unit remains square. The backboard fits **centre to centre** on the upright.

Setup two uprights and 3-4 shelves (including the top and bottom shelf). Use a spare shelf as a square.

Notes:

If using an **outer upright(s)** ensure it is facing the correct way before securing the backboard.

If using a **fascia(s)**, fix to the bottom shelf first before starting to setup your unit(s).

Do not use shelf supports on the top or bottom shelves



Step 2

Carefully lay the backboard on top of the unit ensuring the edge of the backboard is running down the centre of the upright.



Step 3

Nail the back board in the uprights and top and bottom shelves.

Tip:

Start in one corner and work outwards approx every 15/20cm.

Step 4

You can now stand the unit up and add more shelves, or move them around as required. If building a run of units **only build the first one on the floor.**

Tips for a neater finish:

For tall uprights, position the top shelf upside down.
If required the unit/s can be fixed to the wall.

Units over 183cm high and under 30cm deep must be secured to the wall using wall attachments.